



Ultra-Tick is an extrusion coated PVC supported with a polyester base cloth for strength. This construction combines durability with a soft supple finish and is commonly used in general purpose mattress cover applications. Ultra-Tick is available in wide-width which eliminates most joins and features all the regular medical features necessary for a healthcare environment.

## Product Features

---

- Soft Handle
- Hypoallergenic / Non-irritating
- Anti-static
- Fluid Proof
- Anti-bacterial
- Stain Resistant
- Fire Retardant
- Easy to Maintain

## Typical Applications

---

- Healthcare Mattress Covers
- Hostels & Dormitories
- Ambulances & Stretchers
- Childcare Mattresses
- Support Cushions
- Heavy Duty Pillow Covers





## Product Specifications

**Roll Width:** 109cm & 218cm

**Standard Roll Length:** 100m (109cm) & 50m (218cm)

Property	Standard/Test Method	Result
Total Weight	ASTM D3776	340g/m <sup>2</sup>
Tear Strength	AS 2001.1.10 – 1986	81N (warp) 81N (weft)
Tensile Strength	AS 2001.2.3.2 – 2001	539N (warp) 449N (weft)
Adhesion	ASTM D751	10lbs/inch
Flame Resistance (Meets general requirements of the BCA for Class 9A Healthcare Buildings, Specification C1.10)	AS 1530.3 – 1999	Ignitability Index 13 Spread of Flame 0 Heat Evolved Index 0 Smoke Developed Index 5
Anti-microbial	AATCC M30-1998 & AATCC M147-2004	Pass
Electrical Resistivity	NFPA 99	2.3 x 10 <sup>11</sup> ohms (anti-static)



## Care & Maintenance

*Healthcare Fabrics* require regular care & maintenance. If the recommended instructions are followed, the end user can expect to maximise the fabrics potential life and maintain a hygienic environment.

### General Cleaning

Regularly clean **Ultra-Tick** Healthcare Fabrics with a mild solution of phenolic based cleaner and water. Rinse thoroughly with fresh water and wipe dry.

### Spot Cleaning

For difficult spills and stains, prepare a strong solution of phenolic based commercial cleaner. Using a soft bristle brush and solution, clean the affected area. Rinse thoroughly with fresh water and wipe dry.

### Disinfection

It is common to disinfect surfaces in a healthcare environment. Using a water/bleach solution of 10:1, clean the entire mattress. The bleach must not have a sodium hypochlorite level in excess of 5%. Disinfectants applied at full concentration will decrease the life of **Ultra-Tick** Healthcare Fabrics. Rinse thoroughly with fresh water and wipe dry.

### Notes

- Never exceed the cleaning manufacturers concentration recommendations.
- Do not use abrasive cloths or cleaners.
- Do not use aggressive cleaners or chemicals.
- **Ultra-Tick** Healthcare Fabrics are not autoclavable.
- When in doubt, contact your local Nolan Group branch for further advice.